


\*\* depending of configuration

\*Alarm contacts pin 3 and pin 5



When connecting the system to other devices, be sure that the integrity of the shielding is not affected. Do not use unshielded wire terminals.